

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

Copyright© 2007 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 2-290

FAIRING SIDE LOUVER COVERS
HONDA GL1500-6 GOLDWING

Revised 7/25/2017

ITEMS REQUIRED: FLAT BLADE SCREWDRIVER #2 MEDIUM PHILLIPS SCREWDRIVER

INSTALLATION:

1. REMOVE THE FOLLOWING:

- A. PULL OUTWARD ON THE FAIRING FRONT COVER (1A) TO DISENGAGE THE BOSSES (1B) FROM THE FAIRING PANEL COVERS (2A).
- B. USING THE FLAT BLADE SCREWDRIVER, PRY OFF THE L/R BLACK PLASTIC UPPER SIDE TRIM PIECES (2B). **NOTE: EACH SIDE HAS ONE LARGE AND ONE SMALL TRIM PIECE TO BE REMOVED.**
- C. USING THE FLAT BLADE SCREWDRIVER, PRY OFF THE SCREW COVER (2C) FROM L/R LOWER FAIRING CORNER MOLDING TRIM (2D).
- D. USING THE #2 PHILLIPS SCREWDRIVER, REMOVE THE SCREW (2E) FROM THE L/R LOWER FAIRING CORNER MOLDING TRIM PIECES (2D).
- E. USING THE #2 PHILLIPS SCREWDRIVER, REMOVE THE THREE SCREWS (2F) FROM THE L/R LOWER FAIRING PANEL COVERS (2A).
- F. REMOVE THE L/R FAIRING PANEL COVERS (2A).
- G. USING THE #2 PHILLIPS SCREWDRIVER, REMOVE THE FOUR SCREWS (3A) AND THE L/R SIDE LOUVER VENTS (3B) FROM THE FAIRING PANEL COVERS (3C).

2. POSITION THE L/R CHROMED FAIRING SIDE LOUVER COVER (3D) ONTO THE FAIRING PANEL COVERS (3C) WITH THE NARROW END (3E) TO THE REAR AND THE FLAT FACE (3F) INBOARD. **NOTE: ALL FOUR CORNER NOTCHES (3G) MUST FIT AROUND THE SCREW BOSSES (3H) ON THE FAIRING PANEL COVERS (3C).**

3. RE-INSTALL ALL ITEMS REMOVED BY REVERSING STEPS 1A THROUGH 1G.

