

Copyright © 2017 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. V30-202BK

GAS TANK MINI BRA

FITMENT: INDIAN CHIEF, CHIEFTAIN, ROADMASTER 2014-NEWER

3/22/2017

TOOLS NEEDED: 5MM ALLEN WRENCH

6MM ALLEN WRENCH

RUBBING ALCOHOL

LINT FREE TOWEL

REMOVABLE THREAD LOCK

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING. USE REMOVABLE THREAD LOCK ON ALL SCREWS.**ESTIMATED INSTALLATION TIME: 15 TO 20 MIN.****INSTALLATION:**

1. REMOVE BOTH SIDE COVERS FROM BIKE.
2. USING A 6MM ALLEN WRENCH REMOVE THE SCREWS FROM EACH SIDE AS SHOWN IN FIG. 1.
3. USING A 5MM ALLEN WRENCH REMOVE THE SCREW SHOWN IN FIG. 2. **NOTE: SINGLE RIDER SEATS WILL NOT HAVE THIS SCREW.**
4. LIFT SEAT UP AND UNPLUG ANY CONNECTORS. SET SEAT ASIDE.
5. DISCONNECT THE TANK STRAP FROM THE PLASTIC STUD AS SHOWN IN FIG. 3.
6. CLEAN THE REAR HALF OF THE GAS TANK INCLUDING THE UNDERSIDE WITH RUBBING ALCOHOL AND LET DRY.
7. REMOVE THE TWO 2" STRIPS OF HOOK FROM THE MINI BRA AND ATTACH THEM TO THE TOP OF THE GAS TANK AS SHOWN IN FIG. 3.
8. PLACE THE MINI BRA ON THE HOOK YOU JUST INSTALLED AND REATTACH THE TANK STRAP AS SHOWN IN FIG. 4.
9. STARTING ON THE RIGHT SIDE REMOVE THE CLEAR FILM FROM THE 8" LONG PIECE OF HOOK. STRETCH AND ATTACH IT TO THE BOTTOM OF THE GAS TANK AS SHOWN IN FIG. 5.
10. REPEAT THIS FOR THE 8" PIECE ON THE LEFT SIDE OF THE GAS TANK. **NOTE: CAREFULLY SLIDE BETWEEN THE TANK AND THE AIR CLEAN WITHOUT LETTING THE ADHESIVE ON THE HOOK TOUCH THE GAS TANK.**
11. REMOVE THE CLEAR FILM FROM THE 1" PIECES ON THE BACK OF THE MINI BRA AND ATTACH AS SHOWN IN FIG. 6.
12. REINSTALL SEAT AND SIDE PANELS.
13. THE ADHESIVE ON THE HOOK TAKES 24 HOURS TO CURE AFTER INSTALLATION.

